



# Dealer4



---

**Reference:**

<http://www.dealer4.com/Manuals/Dealer4+%20operation%20manual%201v0.pdf>



# Dealer 4

## Preparation

- \* Copy your hand records from your DealFiles folder onto a flash drive
- \* Remove cards from boards  
(don't open them till needed)  
(make stacks of 3 decks)  
(take cards 31-36 first)
- \* GENTLY open boards by tabs  
(NOTE: 3rd tab in middle)



# Dealer 4


## Preparation

- \* Don't use top to pull boards out (hinges are fragile)
- \* Make sure cards are fully in trays before you close them (NOTE: 3rd tab in the middle)
- \* New cards in a clean D4 machine deal in 5-7 seconds (clean rollers or replace cards if approaching 10 seconds!)



# Dealer 4



## Parts





# Dealer 4



## Touch Screen





# Dealer 4


## USB Navigation





# Dealer 4

## Dealing Boards





# Dealer 4

## Dealing Diagnostics

8

♠AK74

♥9762

♦K9

File: 8boards.bri

♠T963

♥AT5

♦62

♣A63

Time: 7

N	E	W
13	13	13

Last board dealt

Go to the first board?

OK

Cancel

Standard

Standard

Standard

Normal

ON

ck: OFF

e: 8boards.bri

Prev

Next

Deal

Deal Next

▲

♠T963

♥AT5

♦62

♣A63

Time: 3

N	E	W
0	0	0

Card Recognition Error

Error no: 25

Continue

Cancel

Standard

Standard

Standard

Normal

ON

ck: OFF

Prev

Next

Deal

Deal Next

▲



# Dealer 4

## Common D4 Error Messages

- \* Card Did Not Go To, or Extra Card To
- \* Card Jam Error
- \* Card Recognition Error
  - Duplicate Card
  - Card does not belong to National Set
- \* Card Feeding Error
- \* Flip Plate Open
  - No Top Cover
  - Board Not Fitted Correctly